

BEFORE YOU BEGIN

In order to take advantage of the Amazon Alexa voice-control feature for your PowerView® Scenes, you need:

- An Alexa-enabled device connected to your Amazon Account
- The Alexa App downloaded and installed on your mobile device
- A PowerView® Account with a PowerView® Hub registered to the account

- 1 Open the Alexa App on your mobile device and select the menu in the upper left hand corner of the screen.
- 2 Select the Skills tab and search for the PowerView® Scenes Skill in the search bar.
- 3 Select the PowerView® Scenes Skill and select Enable.

Enter your PowerView® Account information to link your PowerView® Account with your Amazon Account. Then, authorize your profile and PowerView® Scenes to be shared with Alexa.
- 4 After prompted, select Discover Devices.

All discovered PowerView® Scenes appear in the Scenes section of the Smart Home tab.
- 5 Simply say “Alexa, turn on” followed by the PowerView® Scene name to voice-activate your Scenes.

Sample Commands:

 - “Alexa, turn on Good Morning.”
 - “Alexa, turn on I’m Home.”
 - “Alexa, turn on Movie Time in Living Room.”

TIPS

- Before attempting to discover PowerView® Scenes in the Alexa App, please ensure your PowerView® Hub is registered to your PowerView® Account.
- After your PowerView® Scenes have been discovered in the Alexa App, use the Groups menu in the Smart Home tab to combine your PowerView® Scenes with other smart devices within your home. You may also use it to group together multiple PowerView® Scenes, such as Shade Scenes and Repeater Scenes, for integrated voice-activated control.
- If you did not discover all of your PowerView® Scenes after linking to your account, or you need to discover new Scenes in the future, you can always discover more PowerView® Scenes by selecting “Discover” in the Scenes menu of the Smart Home tab in the Alexa App.
- For more information, please refer to the “About This Skill” section of the PowerView® Scenes Skill in your Alexa App.

